

# Sirius Vacuum System

*Rafael Seraphim*  
*LNLS Vacuum Group*

- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster



- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster

# Storage ring: Vacuum system layout

## Compact lattice and small aperture magnets


- Avg. clearance with magnets < 0.6 mm (with bake-out heating tapes wrapped)

## Pumping strategy

- Most of the inner surfaces will be NEG coated (except RF-cavities, bellows, valves and BPMs).
- Only 3 pumping stations (20 l/s) per superperiod.

## Chamber materials




- OFS copper
- Stainless steel (flanges, pumping ports and fast orbit correctors)
- Glidcop® (ID extraction)




- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster



## Storage ring: Chambers and components design concept




# Storage ring: Chambers and components design concept



# Storage ring: Chambers and components design concept

## Modified KEK MO-type flange (circular and non-circular):

- No gap
- No step
- Continuous copper inner surface








# Storage ring: Chambers and components design concept

## Bellows – design under study

- Built-in flanges on both sides
- Only one design
- Max. compression: 11 mm
- Max. expansion: 2 mm
- Lateral displacements will be absorbed by copper chambers.



Standard design – tapered transition






Similar to DAFNE design (omega stripe)

# Storage ring: Chambers and components design concept

## BPMs

- Stainless steel body
- Built-in flanges on both sides
- Brazed button-feedthroughs



- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster




# Storage ring: Cleaning process and NEG coating

A new cleaning procedure has been developed to avoid aggressive chemicals

- 10% ammonium persulfate + 0,1% ammonium acetate (etching ~ 15  $\mu\text{m}$ )
- 5%  $\text{H}_2\text{O}_2$  (helps to remove silver insoluble residuals)
- 5% ammonium citrate (passivation)

-- Surface roughness < 0.4  $\mu\text{m}$  (Ra) --

XPS analysis – LNLS cleaned surface



Cleaning facility – recirculation system

Cleaning quality criteria:

- Atomic % C < 44
- Halogens (ex. F, Cl) < 1%
- Other contaminants will be analyzed

# Storage ring: Cleaning process and NEG coating

## Main characteristics

- Deposition of up to 3.2 m long chambers
- Magnetic field up to 600 Gauss
- Up to 6 straight chambers simultaneously
- Bake-out system integrated to the solenoids
- Automatic control of the deposition
- Individual control of each chamber

## NEG coating setup



Loading the system for NEG coating run

# Storage ring: Cleaning process and NEG coating




## Present stage

- NEG coating process optimization and studies for circular profile: straight and bent chambers

## Film composition changes by varying the deposition parameters - EDS analysis

Dep name	Ti at%	V at%	Zr at%
0001P-inoxCF40-NEG-06-05-2014	26,85	54,18	18,97
0002P-inoxCF40-NEG-13-05-2014	23,32	48,32	28,36
0003P-inoxCF40-NEG-20-05-2014	26,09	52,12	21,79
0004P-inoxCF40-NEG-23-05-2014	25,45	53,04	21,51
0005P-inoxCF40-NEG-28-05-2014	24,93	50,00	25,07
0007P-inoxCF40-NEG-12-06-2014	34,96	41,06	23,98
0009P-inoxCF40-NEG-03-07-2014	33,35	46,30	20,34
0010P-inoxCF40-NEG-08-07-2014	32,07	49,58	18,35
0012P-inoxCF40-NEG-28-07-2014	32,79	50,43	16,79
0013P-inoxCF40-NEG-30-07-2014	32,83	49,42	17,75
0015P-inoxCF40-NEG-08-08-2014	32,85	49,37	17,78
0017P-inoxCF40-NEG-18-08-2014	32,19	49,28	18,53

## XPS analysis – NEG film activation behavior






# Storage ring: Cleaning process and NEG coating

## NEG film studies

- Aging effect
- Photon induced desorption studies



### Aging effect



## Photon desorption studies of NEG films

50 mm ID NEG coated copper tube


Photoelectron collector stretched along the tube





# Storage ring: Cleaning process and NEG coating

Tests for NEG coating of narrow gap channels are in progress.  
Prototype of dipole chamber with beam extraction channel has been cut into two halves.




1st Test  
1 cathode –  
Partial coating –  
bad mag. field  
homogeneity  
along the  
chamber

Pressão kr=1E-1 mbar  
Campo= 600G  
Tensão=295V  
Corrente=60mA



Before coating




2nd Test  
1 cathode –  
Full coating –  
chamber  
repositioned in  
the solenoids

Pressão kr=7.5E-2 mbar  
Campo= 600G  
Tensão=240V  
Corrente=75mA

# Storage ring: Cleaning process and NEG coating


## Narrow gap coating quality evaluation



## Thickness distribution along x



## Film composition distribution along z (EDS analysis)




- Improvements are being studied.
- Coating activation still need to be tested.

- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster





# Storage ring: Chambers storage and Installation

1. After NEG coating, the chambers will be filled with  $N_2$
2. The chambers will be stored in batches according to their assembly on the machine
3. The chambers will be wrapped with the heating tapes
4. The chambers will be installed in the girders
5. The chambers will be connected between girders
6. Make all electrical and hydraulic connections
7. *In-situ* bake-out for NEG activation ( $200\text{ }^{\circ}\text{C}$  @ 24h)



$N_2$  filling and sealing

Chambers storage concept






- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- Booster

# Storage ring: Bake-out for NEG activation

*In-situ* bake-out for NEG activation (200 °C@24h)  
An thin polyimide heating tape (developed by a Brazilian company) is used.

- Thickness < 0.4 mm
- Max. operation temperature 210 °C

Heating tape




With radiation shield layer

Magnet heating results

$$\Delta T_{\text{poles}} = 12.2 \text{ }^{\circ}\text{C}$$

$$\Delta T_{\text{PM}} = 8.8 \text{ }^{\circ}\text{C}$$


Impact of in-situ NEG activation on permanent magnets.



- Storage ring
  - Vacuum system layout
  - Chambers and components design concept
  - Cleaning process and NEG coating
  - Chambers storage and installation
  - Bake-out for NEG activation
- **Booster**

# Booster

- **Material:** Stainless steel
- Circular profile chambers with dimensions of  $\varnothing 36.1 \times 1 \text{ mm}$  (straights) and  $\varnothing 23.4 \times 1 \text{ mm}$  (dipoles)



SR power density= 3.2 W/m:  
No **radiation absorber** or **water cooling** is needed.

A Brazilian company has been chosen to supply the chambers

- The dipole chambers manufacturing has been started

Thank you for your attention!